

# GICOM MBR

## MOLD BUILDER RUBBER LATEX

M07/R3/S0126

**MBR** is an easy brush-on liquid latex for preparing rubber mold. It can be used to duplicate any models from metal, clay, wood, plastic, glass, etc..

### **A. HOW TO USE**

1. Fix in position the model to be duplicated.
2. Stir the MBR and brush it onto model surface in a continuous thin film, forming a 2" flange around the base of the model.
3. Dry the MBR coat properly before continuing to brush-on the following thin layers. Complete the MBR rubber mold with few layers of MBR until approximately 1-3mm of thickness is achieved.
4. Leave the mold to set overnight after the last coat has been applied.
5. Apply some talc or lubricate to avoid the MBR mould from sticking before removing from the model.
6. Clean the brush with soap and warm water.

**Note:** Brass/copper model should be protected with shellac or acrylic lacquer. Clay / plaster and wood model to be protected with sealer or paste wax before applying MBR.

A.

### **B. PRECAUTION**

Wear protective eyewear when using this product. Keep container tightly closed when not in use. Avoid inhalation, ingestion, eye contact and skin contact.

**KEEP OUT OF THE REACH OF CHILDREN.**

C.

### **D. FIRST AID**

- **ORAL** : NOT TO BE TAKEN. If swallowed, do not induce vomiting. **CALL THE PHYSICIAN IMMEDIATELY!**
- **EYES** : In case of eye contact, flush with plenty of running water for 15 minutes and get prompt medical attention.
- **SKIN** : Wash immediately with soap and rinse with plenty of water. Do not use solvents or alcohol to remove product from skin.
- **INHALATION** : Move to fresh air. If not breathing, administer CPR and get medical attention.

**MOULD BUILDER RUBBER LATEX contains** prevulcanised natural rubber latex, water and ammonia. Contact a poison control center for more health information.

### **Presented by Distributor:**

**Helmut Bergk GmbH**  
Röderbergweg 41  
D 60314 Frankfurt am Main  
Phone: +49-69-499930  
Fax: +49-69-94414458  
E Mail: Bergk.GmbH@t-online.de

*The above information is given in good faith and without liability.*